



Switcher Station Selecting an Image



Input/Output Connections



Input 2 has the option of switching between the codec camera and an external source. This external source is either the rear camera or the mobile camera depending on what is seen in Monitor 5.

Output 1 -> Studio 5B Monitors showing the far site
 Output 2 -> Studio 5B Monitors showing the near site
 Output 3 -> Video signal being sent to the far site
 Output 4 -> to the VCR for documentation (same image as Output 3)

Input/Output Buttons on Switcher Router Unit

Select the Input # first,
then the Output #

	Inputs			
Outputs 1	●	○	○	○
2	○	●	○	○
3	○	●	○	○
4	○	●	○	○

If Codec Camera is switched to the External Source then:

3 -> 3 = Preview in Monitor 5 = Far site signal will be seen in Monitor 2 also

OR

4 -> 4 = Preview in Monitor 5 = far site signal will be seen in Monitor 2 also